

MINICURB™ Penetration Seal

The **MiniCurb™** was designed to seal small penetrations such as HVAC conduit and drains, exterior lighting supports, surveillance cameras, mounts for solar panels and light angle-iron struts.

The **MiniCurb** is built with a special fiberglass reinforced nylon that is tough and durable. Its unique slip-fit components permit quick assembly around penetrations that can't be disturbed. **MiniCurbs** are installed with the same adhesive as the larger **ChemCurbs®** and a specially formulated sealant. MiniCurbs have a flanged bottom that allows for external flashing with appropriate membrane material.

Each **MiniCurb** kit contains ten curb component sets and more than enough 1-Part MiniCurb Pourable Sealer and M-1® adhesive to complete all ten curbs.

The MiniCurb Kit



The MiniCurb



Prime



Fill



Finish



Features:	Benefits:
Installs in under 5 minutes	Quick and Convenient
1-PART MINICURB Pourable Sealer	Designed to self level and cure quickly
New "Slip Fit" Technology	Easy Installation
Versatile	Useful in a variety of construction applications
Adaptable	Can be surface mounted or flashed in with traditional roofing materials.

MiniCurbs are installed in the same manner as larger **ChemCurbs**,

- 1) Remove all asphalt or cement from the penetration with a wire brush and clean residual dirt and oil with alcohol. Clean surrounding roofing material as well. (TPO should be primed with ChemLink TPO Primer)
- 2) Seal the base of the penetration with M-1 to prevent drainage of sealant into building.
- 3) Prime the penetration with a film of M-1 to 2 inches above the roof surface.
- 4) Coat the bottom of the flange with a double bead of M-1.
- 5) Place the coated **MiniCurb** components around the penetration and slip the edges together unitizing them into a solid ring.
- 6) **Coat Exterior Seam with Bead of M-1.**
- 7) Firmly press the assembled **MiniCurb** down on the roof membrane until excess adhesive squeezes out at the edges. Wipe off excess adhesive.
- 8) Fill the interior of the **MiniCurb** with **1-Part** pourable sealer. Make sure the interior is filled to the top to prevent water from accumulating at the top.

Read and ensure that the most up-to-date MSDS and technical guidelines are being followed. Proper use and application are the responsibility of the applicator. Direct any questions to Technical Services at 800-826-1681 prior to starting the project.

Chem Link offers a 10 year material warranty against leaks when applied in accordance with Chem Link application instructions stated above, using only specifically MiniCurb components.

IMPORTANT NOTICE:

EXCEPT WHERE PROHIBITED BY LAW, CHEM LINK MAKES NO WARRANTIES, EXPRESS OR IMPLIED, STATUTORY OR OTHERWISE, INCLUDING BUT NOT LIMITED TO, ANY IMPLIED CONDITION OR WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. User is responsible for determining whether this Chem Link product is fit for a particular purpose and suitable for user's method of application.

LIMITATIONS OF REMEDIES AND LIABILITY:

If this Chem Link product is proved to be defective, THE EXCLUSIVE REMEDY AT CHEM LINK'S OPTION SHALL BE TO REFUND THE PURCHASE PRICE OF OR TO REPAIR OR REPLACE THE DEFECTIVE CHEM LINK PRODUCT. Chem Link shall not otherwise be liable for loss of damages, whether direct, indirect special, incidental or consequential, regardless of the legal theory asserted, including negligence, warranty or strict liability.



353 E. Lyon St.
Schoolcraft, MI 49087
800-826-1681 www.chemlinkinc.com Fax 269-679-4448

