

## Lap Seaming Using DoubleStick

Measure DoubleStick.



Proper overlap of Roofing Membrane Seams is 3"

Remove release liner.



Clean Seam Area.  
Peel backing away on BOTTOM side.  
Do this slowly while you apply tape.

Apply DoubleStick and roll.



Start on one end.  
One person should align and pull bottom release liner away.  
The other should smooth tape down with their hand.  
Roll lightly. You will roll more later.

Remove second release liners.



Peel way TOP liner from Doublestick.  
Roll Top membrane into Doublestick slowly, to avoid bubbles.  
Smooth out with your hand as you go.

Roll roof membrane.



Roll WELL to fuse sealant to membranes.

Finish / seal exposed edge with one of these:

- \* M1 Sealant
- \* Coverstrip Tape (requires primer first)
- \* Self-Leveling Seam Sealant
- \* Other approved Cut-Edge Sealant