

## Leak or Seam Repair on EPDM, TPO or PVC using Eternabond RoofSeal.

Find the Leaks.



Inspect all seams, edges, and penetrations.

Clean Surface.



- \* Remove dirt layer.
- \* Clean with EternaClean or other residue free cleaner.
- \* Use a 3m Fine Scotch-Brite pad and scuff surface lightly to create a fresh surface.

Apply Eternabond and Roll.



Peel Back and apply Eternabond RoofSeal slowly, wiping-pressing with your hand as you go, to prevent bubbles and work product into irregular areas.

Roll WELL to fuse sealant to surface.

Do not stretch tape surface.

Distributed by: [BEST MATERIALS LLC](#)  
Ph: 800-474-7570, 602-272-8128 Fax: 602-272-8014  
[www.BestMaterials.com](http://www.BestMaterials.com) Email: [Sales@BestMaterials.com](mailto:Sales@BestMaterials.com)