



Hatch Safety Gate

P.O. Box 1671 Tomball, Tx. 77377


Distributed by:

Best Materials LLC


Phone: **800-474-7570, 602.272.8128**

Email: **sales@bestmaterials.com**

Website: **www.bestmaterials.com**



Hatch shown for reference only



Typical Installation:

Remove corner post, reinstall after installing hinge clamps to post. Before installing gate level corner post by adjusting rear rail (D) check square tubing (A) to see if level. before installing gate line up hinge clamps to gate clip then adjust clamps to levelgate. Slide Hinge pin through gate clip and clamps without spring adjust and level by adjusting hinge clamps until the gate lines up with the side rails, the top of the gate should be level. when gate is level and square remove hinge pins and install spring with the tension pin to the top of the left post. expand and adjust gate frame to needed position and tighten bolts. check and tighten all clamps and bolts.

Model: G2436