

Promatic

Torch Kit Accessories

Best Materials® | Email: Sales@BestMaterials.com | Phone: 1-800-474-7570 | www.BestMaterials.com



3366-97

Sievert Promatic Universal Handle
 Universal handle allows you to change burners in seconds! Automatic trigger start piezo ignition allows you to instantly ignite and extinguish flame with one hand. Adjustable flame control knob is great for detail work! Fits up to 16 different burners. Male LH 9/16" threads.



Load relieving trigger system with automatic Piezo ignition.

Trigger on/off function



Swivel hose nipple.

Precise flame adjustment valve

3353-02

Sievert Promatic Field Burner (with neck tube)
 200-400,000 BTU/hr, length 28", burner diameter 2-1/2", stainless steel construction.



3354-02

Sievert Promatic Field Burner (with neck tube)
 200-400,000 BTU/hr, length 22", burner diameter 2-1/2", stainless steel construction.



3356-02

Sievert Promatic Field Burner (with neck tube)
 200-400,000 BTU/hr, length 10", burner diameter 2-1/2", stainless steel construction.



3350-02

[Click Here To View Pricing](#)

Sievert Promatic Detail Burner (with neck tube)
 88-150,000 BTU/hr, length 15", burner diameter 1-1/2", stainless steel construction.



3344-90

[Click Here To View Pricing](#)

Sievert Promatic Repair/Detail Burner
 26,000 BTU/hr. For Modified Bitumen.



3358-90

Sievert Promatic Hot-air Repair Burner
 3,000 BTU/hr, 1,200°F. For Single Ply.



3334-90

[Click Here To View Pricing](#)

Sievert Promatic Hot-air Burner
 6,000 BTU/hr, 1,200°F. For Single Ply.



7169-41

[Click Here To View Pricing](#)

Sievert Promatic Flat Nozzle
 For use with 3334-90. 2.2" wide x 0.5" opening.



7172-40

[Click Here To View Pricing](#)

Neck tube Support Stand

